

Encore

Premium laundry liquid

Features & Benefits

- Encore dissolves instantly and begins working immediately. No undissolved abrasive lumps remain to damage garments and machines.
- Excellent cleaner for cotton and synthetic fibres, whites and colours.
- Does not contain harsh chemicals and is safe to use on permanent press, drip-dry and other treated fabrics.
- Encore is formulated as a low foaming product and can be used in either front or top-loading machines.
- The controlled suds level minimises rinsing time and water use.
- Encore leaves the machine bowl clean and free from scum.
- Pleasantly fragranced.

Use Directions

Use half to one up per average domestic top-loading washing machine. For front-loading machines, use half a cup per load. Wool should not be washed in Encore, as damage will result; for wool washing use Protein. Do not over load the machine as this will result in poor washing. For best results use hot water.

Packages:

5 litre, 20 litre containers.

PI 08/08